



Copyright ©Sungrow 2019 All Rights Reserved.

[User manual](#) | [Term of service](#) | [Privacy policy](#)

iSolarCloud

Remote Monitoring and O&M Platform

Energy Management User Manual

Contents

| | | |
|--------------|------------------------------------|-----------|
| 1 | About This Manual..... | 1 |
| 1.1 | Target Group | 1 |
| 1.2 | Symbol Explanation..... | 1 |
| 1.3 | Expression Explanation..... | 1 |
| 2 | Common Operation | 2 |
| 2.1 | User Registration..... | 2 |
| 2.2 | Login | 3 |
| 2.3 | Help | 5 |
| 2.4 | Logout..... | 5 |
| 3 | Home | 6 |
| 3.1 | Plant Sharing | 7 |
| 3.1.1 | Sharing Plant..... | 7 |
| 3.1.2 | Publishing Plants | 8 |
| 3.1.3 | Cancelling Sharing..... | 9 |
| 3.2 | Query Plants..... | 9 |
| 3.3 | View Plant Information | 10 |
| 3.3.1 | Overview | 11 |
| 3.3.2 | Device Information | 12 |
| 3.3.3 | Plant Configuration..... | 16 |
| 4 | Fault List..... | 19 |
| 4.1 | View Fault Information..... | 19 |
| 4.2 | Query Fault..... | 20 |
| 4.3 | Close the Fault..... | 20 |
| 4.3.1 | Close Single Fault..... | 20 |
| 4.3.2 | Close Faults in Batch..... | 21 |
| 4.4 | Export Fault..... | 21 |
| 5 | Parameter Setting..... | 23 |
| 5.1 | Query Device | 23 |
| 5.2 | Command Line Parameter Setup | 24 |

| | | |
|------------|---|-----------|
| 5.3 | Initial Grid Connection Setting..... | 25 |
| 5.4 | Parameter Setting..... | 27 |
| 5.5 | View History Tasks..... | 27 |
| 6 | Firmware Update | 29 |
| 6.1 | Firmware Update | 29 |
| 6.2 | View history update tasks..... | 30 |
| 7 | String IV Curve Scan and Diagnosis | 31 |
| 8 | Other Operations | 34 |
| 8.1 | User Information | 34 |
| 8.2 | Account and Security | 34 |
| 8.3 | Account Settings..... | 35 |
| 8.4 | Background Management | 35 |
| 8.5 | Help..... | 35 |
| 9 | Appendix | 36 |
| 9.1 | System Requirements | 36 |
| 9.2 | Manual Description..... | 36 |
| 9.3 | Contact Sungrow | 36 |

1 About This Manual

1.1 Target Group

This manual is intended for dealers, installers, and end users of residential PV plant, energy storage system, and commercial PV plant.

1.2 Symbol Explanation



"NOTE" indicates additional information, emphasized contents, or tips helping you solve problems or save time.

1.3 Expression Explanation

| Type | Example |
|----------------------------------|-----------------------------------|
| Select a certain menu or option | Select "Plant overview" |
| Select multiple menus or options | Select "All plants -> Plant unit" |
| Select a certain button | Select 【Confirm】 |

2 Common Operation



Images in this document are for reference only, and the actual interfaces may differ.

2.1 User Registration


Register to get an account and a password.

The users are divided into end user and installer/retailer.

The end user can view plant information, create plants, set parameters, share plants, etc.

The installer/retailer can help the owner create plants, manage installed/maintained plants, and manage users and organizations.

Step1 Click "Register" to enter the registration interface.



Step2 Select the corresponding user role (end user or installer/retailer).

iSolarCloud™ | Register

Register

End user

iSolarCloud of International

Mailbox

Validate code

Password

Confirm password

Please select country(region)

Select the time zone

Agree with service terms and conditions

Register

iSolarCloud™ | Register

Register

End user

Installer/Retailer

iSolarCloud of International

Mailbox

Validate code

Password

Confirm password

Please select country(region)

Select the time zone

Company name

code of upper level Installer/Retailer

Agree with service terms and conditions


Register

- i**
- Users in Europe and Africa should select "Europe station". Users in Europe and Africa should select "Europe station". Users in regions other than mainland China, Europe, and Africa should select "International station".
 - Users whose server site is "China station" cannot register account yet.
 - The installer/retailer may enter the company name or the code of upper level installer/retailer during registration. The code of upper level installer/retailer can be obtained from the superior dealer/installer. Filling in the code of the upper level installer/retailer indicates that your organization belongs to the superior installer/retailer organization.

2.2 Login

Step1 Enter the specific address in the address bar, for example, <https://www.isolarcloud.com> to enter the login interface.

Step2 Select the desired language.



Step3 The system automatically switches to the corresponding site according to user IP, or the user may manually switch to the site. Users in mainland China should select "China station". Users in Europe and Africa should select "Europe station". Users in other regions should select "International station".



Step4 Enter the username and password in the login dialog box. Click 【Login】.




For the convenience of subsequent login, the user may select "Remember me".

Login successfully

If no residential plant is bound, the prompt: "The current user has not yet bound a plant" pops up.

2.3 Help



Click "User manual", "Terms of service" and "Privacy policy" on the bottom of the login interface to view corresponding information.

2.4 Logout

Click "Logout" to exit the system.

3 Home

After login, the user enters the home page, as shown in the figure below.

The screenshot shows the iSolarCloud Home interface. On the left is a sidebar with navigation links: Home, Fault, Report, Settings, Firmware update, String IV curve scan and diagnosis, Help, Account, Me, Account settings, Account and security, Background management, and Logout. The main area displays a table of power plants. The columns are: Image, Plant state, Plant name, Plant type, Power installed, Real-time power, Yield today, and Operation. There are 8 entries in the table, each with a small image, status, name, type, power rating, and control icons. At the bottom right of the table are pagination controls: Total 2097, 10/page, and Go to 1.

| Image | Plant state | Plant name | Plant type | Power installed | Real-time power | Yield today | Operation | |
|-------|-------------|--------------------------------|-----------------|-----------------|-----------------|-------------|-----------|--|
| | | 1211092618P的电站, wHy_bank光模块 8a | Residential(PV) | 5.32 kWp | -- | -- | | |
| | | 1233447 | Residential(PV) | -- | -- | -- | | |
| | | 1655653654555554 plant | Residential(PV) | 9.29 kWp | -- | -- | | |
| | | 1708041160P的电站 | Residential(PV) | 5 kWp | -- | -- | | |
| | | 20180724r9的电站 | Residential(PV) | 200 kWp | -- | -- | | |
| | | 20190118ee的电站 | Distributed PV | 3 kWp | -- | -- | | |
| | | 20191234qe的电站 | Residential(PV) | 5 kWp | -- | -- | | |
| | | 2308041204P的电站 | Distributed PV | 1.5 MWp | -- | -- | | |



Permissions of the installer/retailer and the end user are different. The end user does not have permissions of device upgrading, string IV curve and diagnosis and background management.

3.1 Plant Sharing

| Image | Plant state | Plant name | Plant type | Power installed | Real-time power | Yield today | Operation |
|-------|-------------|----------------------------|----------------------|-----------------|-----------------|-------------|-----------|
| | | 1211092618的电站_why_bank光伏电站 | Residential(PV) | 1.2MWp | -- | -- | |
| | | 130510173的电站_why_bank测试电站 | Distributed PV | 1.29GWp | -- | -- | |
| | | A18102816758的电站 | Residential(Storage) | 5kWp | -- | 0kWh | |

Total 3 10/page < 1 > Go to 1

The plant list includes plants of the end user and plants shared by other end users.

3.1.1 Sharing Plant



Only the end user can share plants, and the installer/retailer do not have the sharing permission but can receive shared message.


Step1 Click the button “”, to enter the sharing interface.

| Image | Plant state | Plant name | Plant type | Power installed | Image | Email | Sharing Authority | Operation |
|-------|-------------|----------------------------|-----------------|-----------------|-------|------------------|-------------------|-----------|
| | | 1211092618的电站_why_bank光伏电站 | Residential(PV) | 1.2MWp | | 12345678@163.com | Manage... | |
| | | 130510173的电站_why_bank测试电站 | Distributed PV | 1.29GWp | | ghm_h@163.com | Read ... | |
| | | 17080411608的电站 | Residential(PV) | 5kWp | | | | |

Publish power station
When open, this station can be visited by tourists

Close

Step2 Click "ADD Share" to enter the corresponding interface.




Step3 Fill in the e-mail address and click "Confirm" to share the plant.



Plants can be shared to at most 6 users who have the management permission, but the number of users with view permission is not limited.

3.1.2 Publishing Plants




When the option "Publish power station" is turned on, plants can be shared to visitors.

3.1.3 Cancelling Sharing


For sharer:

Click the button "  " on the operation bar, to cancel the sharing of the plant.




For receiver:

Click the button "  " on the operation bar to unbind the sharing relationship, after which the user cannot view or manage the plant.



3.2 Query Plants

Select the plant state, plant type, enter plant name, and click the button "Search", to query corresponding plants.




| Image | Plant state | Plant name | Plant type | Power installed | Real-time power | Yield today | Operation |
|-------|-------------|----------------------------|-----------------|-----------------|-----------------|-------------|-----------|
| | | 00099222的电站 | Residential(PV) | 66kW | -- | -- | |
| | | 012385fjgy/byh6的电站 | Residential(PV) | 20kW | -- | -- | |
| | | 1210085300的电站_why_bark测试 | Residential(PV) | 123.69MW | -- | -- | |
| | | 121109261的电站_why_bark光伏电站 | Residential(PV) | 1.2MW | -- | -- | |
| | | 1220的电站这份喜欢✓要会向派出成功则通过后... | Residential(PV) | 2kW | -- | -- | |
| | | 128880的电站 | Residential(PV) | 12kW | -- | -- | |
| | | 165565565455555s plant | Residential(PV) | 9.29kW | -- | -- | |
| | | 1708041160的电站 | Residential(PV) | 5kW | -- | -- | |

Total 2502 10/page < 1 2 3 4 5 6 ... 251 > Go to 1

3.3 View Plant Information

Click the plant name to enter the plant information interface.




| Image | Plant state | Plant name | Plant type | Power installed | Real-time power | Yield today | Operation |
|-------|-------------|---------------------|-----------------|-----------------|-----------------|-------------|-----------|
| | | A180802105799电站 | Residential(PV) | 5kW | 3.72kW | 30.3kWh | |
| | | 移动硬盘1806092561的电站 | Residential(PV) | 10kW | 1.53kW | 0.9kWh | |
| | | A1806162898的电站 | Residential(PV) | 5kW | 0W | 0kWh | |
| | | A1806163087的电站 | Residential(PV) | 6kW | 736W | 0kWh | |
| | | 5G8K_A1806163070的电站 | Residential(PV) | 8kW | 0W | 0kWh | |
| | | Y1808150037的电站 | Residential(PV) | 80kW | -- | 0kWh | |
| | | A1810281223的电站 | Residential(PV) | 5kW | -- | 0kWh | |
| | | B1811191516@038 | Residential(PV) | 5kW | -- | 0kWh | |

Total 2502 10/page < 1 2 3 4 5 6 ... 251 > Go to 1



3.3.1 Overview




On the "overview" interface, users can perform the following operations:


- View basic plant information, including today income, real-time power, yield in this month, total yield, CO₂ reduction, etc.
- View tidal current diagram, including information such as real-time power, feed-in power, load power, battery charging/discharging information, etc.

The energy storage system and PV system have different tidal current diagrams.

The tidal current diagram of the energy storage system is as follows:




The tidal current diagram of the PV system is as follows:



1. The line with an arrow indicates energy flow between connected devices, and the arrow pointing indicates energy flow direction
 2. Gray line indicates that the connected devices are off-line.
- View and export plant data. The data can be viewed or exported based on "Day", "Month", "Year", and 'Total'.



Parameters on the PV side and load side can be viewed.



Select a time segment and click " " in the upper right corner of the chart, to export the chart.


Click " " to change the curve form into the table form.

- View plant running status, including "Normal" , "Fault" , "Offline" , and "Connecting"

3.3.2 Device Information


Click "Device Info" to enter the device information interface. Users can view device basic

information and alarm information.



Search device

Enter the device name, select the device type and device status, and click "Search".



View basic device information

Click the device name to view basic device information, device alarm (closed), device alarm (open), and chart information.

- View basic device information

Click the device name, select "Device Basic Info" to view the measuring point information and device information, or restore faults.

| SH5K_1 | | | | | | | | |
|---|----------|--------------------|---|-----------|------------------------------------|--------------------------------------|-----------|---|
| Plant name: A1810040424 Device space: A1810040424 Device model: SH5K-20 | | | | | | | | |
| Device Basic Info | | Device alarm(open) | Device alarm(closed) | Chart | Data update time: 2019-01-22 14:40 | | | |
| Measuring point parameter | | | | | | | | |
| Daily amount of electricity taken from grid | 0 kWh | ✓ | Total amount of electricity taken from grid | 1,058 MWh | ✓ | P-energy get from grid | 0 W | ✓ |
| Bus voltage | 0 V | ✓ | Operating type | 0 | ✓ | MDSGP off-grid start up state | 2 | ✓ |
| SDSP off-grid start state | 2 | ✓ | DI status | 6 | ✓ | Battery voltage (BMS) | 5,796 V | ✓ |
| EMS status | 3 | ✓ | PV daily feed-in power | 0.8 kWh | ✓ | Daily direct energy consumption | 0 kWh | ✓ |
| Annual direct energy consumption | -- kWh | ✓ | PV total feed-in power | 151.9 kWh | ✓ | Total direct energy consumption(BMS) | 44.7 kWh | ✓ |
| | | | | | | Total PV battery charge | 26.8 kWh | ✓ |
| PV information | | | | | | | | |
| PV1 voltage | 402.3 V | ✓ | PV1 current | 2.2 A | ✓ | PV2 voltage | 0 V | ✓ |
| PV total power | 924 W | ✓ | Daily PV power generation | 0.9 kWh | ✓ | Total PV energy generation | 223.4 kWh | ✓ |
| Battery information | | | | | | | | |
| Battery voltage | 58.7 V | ✓ | Battery current | 0 A | ✓ | Battery charging power | 0 W | ✓ |
| Battery capacity | 98.8 % | ✓ | Battery SOH | 100 % | ✓ | Battery temperature | 17 °C | ✓ |
| Max. discharging current (BMS) | 80 A | ✓ | Daily battery discharging energy | 0 kWh | ✓ | Max. charging current (BMS) | 32 A | ✓ |
| Total battery charging capacity | 46.9 kWh | ✓ | Daily battery charging energy | 0.3 kWh | ✓ | Total battery discharging capacity | 26.8 kWh | ✓ |
| | | | | | | | | |


Repair

Click the button "  " to view history information.

Select the start time, end time, and time interval, and then click the button "Search".



Click "  " to change the graph into report. Click "Save table data" to export data.



Click "⟳" in the upper right corner of the interface to refresh the interface.

- Repair

Click "Repair" to enter the corresponding interface.

| | | | |
|--------------|-------------|-------------------|-----------------------|
| Plant name | A1810040424 | Device type | Energy storage system |
| * Fault name | Select | * Fault device | Select |
| * Fault type | | * Fault level | |
| * Source | Select | * Processing time | Emergency |

Fault details

Fault picture

Device alarm (open) information interface

Select the time range, fault name, alarm level, and alarm processing state, and click the button "Search" to view corresponding information.

| Device name | Fault type | Fault level | State | Fault name | Reporter | Occurrence time |
|-------------|------------|-------------|-------|------------|----------|-----------------|
| No Data | | | | | | |

View device alarm (close) information

Select time range, fault name, and alarm level, and then click the button "Search".

| SH5K_1 | | | | | | | | |
|--|---|---|---|------------------------------------|----------|--|--|--|
| Device Basic Info | | Device alarm(open) | | Device alarm(closed) | | Chart | | |
| time frame: | | | Fault name: | | | | | |
| <input type="button" value="2019-01"/> | | | | | | <input type="button" value="Q. Search"/> | | |
| Alarm level: | <input checked="" type="checkbox"/> Important | <input checked="" type="checkbox"/> Secondary | <input checked="" type="checkbox"/> General | | | | | |
| Device name | Fault type | Fault level | State | Fault name | Reporter | Occurrence time | | |
| SH5K_1 | Fault | General | Closed | BMS com abn | system | 2019-01-21 23:22:28 | | |
| SH5K_1 | Fault | General | Closed | 10 minutes grid overvoltage | 王文杰2 | 2019-01-21 08:48:07 | | |
| SH5K_1 | Fault | General | Closed | 10 minutes grid overvoltage | 王文杰2 | 2019-01-21 08:45:31 | | |
| SH5K_1 | Fault | General | Closed | Battery average undervoltage fault | system | 2019-01-20 23:48:12 | | |
| SH5K_1 | Fault | General | Closed | Off-grid BOX box D fault | system | 2019-01-20 23:27:41 | | |
| SH5K_1 | Fault | General | Closed | Islanding | system | 2019-01-20 23:27:35 | | |
| SH5K_1 | Fault | General | Closed | Phase A I sampling channel | 王文杰2 | 2019-01-18 14:37:54 | | |
| SH5K_1 | Fault | General | Closed | Comm exception | 王文杰2 | 2019-01-18 09:21:24 | | |
| SH5K_1 | Fault | General | Closed | 10 minutes grid overvoltage | 王文杰2 | 2018-01-17 09:03:18 | | |
| SH5K_1 | Fault | General | Closed | Islanding | system | 2019-01-16 15:02:41 | | |

View the Chart

Select a time range and refresh interval to view corresponding curve, and click "Download" to download the curve.



3.3.3 Plant Configuration

Plant Configuration

Click "Plant configuration" -> "Plant configuration" to enter the corresponding interface.

Basic information such as plant name, power installed, and plant grid-connection type can be configured.

Plant configuration

* Plant name
B1809030481的电站

Owner's email

Power installed
3 kWp * Setting
Participate in the calculation of parameters.
Please modify it with caution

Plant type
Residential(PV)

Grid-connection type
Select

Location

Save

Time zone
(UTC +08:00) Beijing, Chongqing...

Create time
2019-01-25

Grid-connection time
2019-01-25

Station delivery address ⓘ
 Please enter

Station delivery zip ⓘ
 Please enter

Distribution/installer organization code

Installer/Retailer

Contact info of installer
19988888888

Save

Installer/retailer organization cod

End user

- The end user can fill in the dealer/installer organization code to appoint the corresponding installer/retailer to manage the plant. The organization code can be obtained from the installer/retailer.
- The end user can change the organization code to appoint another installer/retailer to manage the plant.

Installer/retailer

- The installer/retailer can change the organization code to manage another plant, after which the installer/retailer cannot not manage the previous plant.

Electricity price configuration

Click "Plant configuration"-> "Electricity price configuration" to enter the corresponding interface.

Users may set the power price value or turn on the option "TOU power price"

- Set electricity price

The screenshot shows a simplified version of the electricity price configuration interface. It includes fields for 'Charge unit' (set to GBP/kWh), a 'Power price' input field containing '0.365', and a toggle switch labeled 'TOU power price' which is currently off. A blue 'Save' button is at the bottom.

- Set TOU power price

This screenshot shows the full TOU power price configuration interface. It includes a 'Charge unit' dropdown (GBP/kWh), a 'Power price' input field (0.365), and a 'TOU power price' toggle switch which is turned on and highlighted with a red box. Below these are sections for 'Time Interval' and 'Price in other time period'. The 'Time Interval' section contains two rows of data:

| Start time | End time | Price | Operation |
|------------|----------|-------|-----------|
| 18:46 | 18:47 | 2.3 | edit icon |
| 19:46 | 20:48 | 2.38 | edit icon |

A blue 'Add' button is located to the right of the table. The 'Price in other time period' section has a single input field containing '0.365'. A blue 'Save' button is at the bottom.

Fault alarm push mode

Click "Plant configuration"-> "Fault alarm push mode" to enter the corresponding interface.

Users can set the fault notification method on this interface.

The screenshot shows the fault alarm push mode configuration interface. It includes a 'Owner's email' section with an input field containing 'Reception mailbox push' and a note '(There is no email information, you can add email information in the basic information of the account !)'. A blue 'Save' button is at the bottom.

4 Fault List

Click "Fault Alarm" to enter the fault list interface and view the plant alarm information.


The screenshot shows a software interface for managing plant alarms. At the top, there are filters for 'Time' (set to 2018-01-25 to 2019-01-25), 'Alarm name' (empty), and 'Alarm type' (checkboxes for Fault, Alarm, Prompt, Advice, Important, Secondary, General, all of which are checked). There is also a 'Refresh time' button set to 5 min and a 'Batch close' button. Below the filters is a table with columns: Plant name, Alarm type, Alarm level, Alarm name, Device name, Occurrence time, and Operation. The table lists numerous alarms from various devices like SGK-D_1, SGK-D_V39_3, SGK-D_1, etc., with details such as PV2 reverse connection fault, Grid V-under, PV1 overcurrent, etc. At the bottom left is a sidebar titled 'Input plant name' containing a list of recent or important events. At the bottom right are pagination controls (Total 628, 10/page, 2, 3, 4, 5, 6, ..., 63, Go to) and a refresh icon.

Faults, alarms, and advice not closed within one year can be viewed by default.

Click Refresh time 5 min on the upper right corner to refresh the interface according to the selected time interval. Click to refresh the interface.

4.1 View Fault Information

Click the button " " on the operation bar, to enter the fault detail interface and view detailed fault information.



4.2 Query Fault


Select a time segment, enter the alarm name, and click "Search" to view the corresponding fault, alarm, and advice information.

| Plant name | Alarm type | Alarm level | Alarm name | Device name | Occurrence time | Operation |
|----------------------|------------|-------------|--------------------------------------|----------------|---------------------|-----------|
| 王嘴测点电站的电站 | Alarm | General | AFD module abnormal alarm | SG50KTL-M-G2_2 | 2019-01-22 19:42:01 | |
| A1802080082的电站 | Alarm | General | AFD module abnormal alarm | SG8KTL-M_1 | 2019-01-22 14:39:29 | |
| 110510173的电站_wh_bank | Alarm | General | 2nd combining abn alarm | 王家坝1-1 | 2019-01-21 21:12:02 | |
| 230测试104的电站 | Alarm | General | 18th string reverse connection alarm | HW_50KTL_1 | 2019-01-21 21:11:41 | |
| T2018111461的SV测试的电站 | Alarm | General | 32nd string reverse connection alarm | SG40KTL-M-4 | 2019-01-14 23:27:50 | |
| A1801058888的电站 | Alarm | General | BDC F sensor open circuit alarm | SHSK_1 | 2019-01-14 13:22:25 | |
| TR12344321大机做人 | Alarm | General | AFD module abnormal alarm | SG3125HV-PC-1 | 2019-01-10 13:45:27 | |
| A181105241089的电站 | Alarm | General | 6th string reverse conn alarm | SG40KTL-M-G2_2 | 2018-12-30 09:16:18 | |
| L18011300401的电站 | Alarm | General | 6th string reverse conn alarm | SG40KTL-M-G2_1 | 2018-12-24 08:20:44 | |

4.3 Close the Fault


4.3.1 Close Single Fault

Click the button on the operation bar, to enter the close interface. Fill in the processing opinion and then click the button "Close fault".




4.3.2 Close Faults in Batch

Click "Batch close" to enter the fault close interface. Fill in the processing opinion and then click the button "Close fault".



4.4 Export Fault

Select a fault, and click the button to export the fault information.



The screenshot shows a software interface for managing alarm logs. At the top, there is a search bar with 'Input plant name' and a dropdown menu with options 'Open' and 'Closed'. Below the search bar are filters for 'Time' (set to 2018-01-25 to 2019-01-25), 'Alarm name' (containing 'alarm'), and 'Alarm type' (set to 'Fault'). There are also checkboxes for 'Important', 'Secondary', 'Prompt', and 'Advice' under 'Alarm level'. A 'Search' button and a 'Batch close' button are located at the top right. The main area is a table with the following columns: Plant name, Alarm type, Alarm level, Alarm name, Device name, Occurrence time, and Operation. The table lists 19 rows of alarm data. The last row is partially cut off. The bottom of the table has pagination controls: 'Total 19', '10/page', and buttons for page numbers 1, 2, and 3.

| Plant name | Alarm type | Alarm level | Alarm name | Device name | Occurrence time | Operation |
|------------------|------------|-------------|---|------------------|---------------------|-----------|
| A180105888889@站 | Alarm | General | BDC-T sensor open circuit alarm | SHSK_1 | 2019-01-14 13:22:25 | |
| TR12344321大机跳入 | Alarm | General | AFD module abnormal alarm | SG40KTL-M-G2_1 | 2019-01-10 13:45:27 | |
| A1811052419@站 | Alarm | General | 6th string reverse comm alarm | SG40KTL-M-G2_2 | 2018-12-30 09:16:18 | |
| L18011300401@站 | Alarm | General | 6th string reverse comm alarm | SG40KTL-M-G2_1 | 2018-12-24 08:20:44 | |
| A1808281653@站 | Alarm | General | 6th string reverse comm alarm | SG40KTL-M-G2_2 | 2018-12-15 11:04:10 | |
| A180105888889@站 | Alarm | General | Ambient temperature sensor open circuit alarm | SHSK_1 | 2018-12-13 11:52:07 | |
| A180105888889@站 | Alarm | General | Inversion-T sensor open circuit alarm | SHSK_1 | 2018-12-13 11:51:17 | |
| CGK@1811052419@站 | Alarm | General | 27th string reverse comm alarm | CGK@1811052419@站 | 2018-12-13 11:50:00 | |

5 Parameter Setting

Click "Setting" to enter the parameter setting interface.

The screenshot shows a web-based interface for parameter setting. At the top, there is a search bar with placeholder text "Input plant name" and a magnifying glass icon. Below the search bar are four dropdown menus: "Inverter model" (set to "All"), "Country(region)" (set to "All"), "Grid type" (set to "All"), and "Version no." (set to "All"). A "Search" button is located to the right of these dropdowns. Below the search area is a table with columns: Plant name, Device name, Device SN, Inverter model, Country(region), Grid type, Version no., Device space, and Operation. The table contains several rows of data, each representing a different inverter unit. At the bottom of the table, there are navigation links for "Total 2089", "10/page", and "Go to 1".

| Plant name | Device name | Device SN | Inverter model | Country(region) | Grid type | Version no. | Device space | Operation |
|-----------------------|-------------|-----------|----------------|-----------------|-----------|-------------|--------------|-----------------------|
| 1211092618的电站_why... | | | | | | | | 1211092618的... |
| 130510173的电站_why... | | | | | | | | 130510173的... |
| 1708041160的电站 | | | | | | | | 1708041160的... |
| 201912346的电站 | | | | | | | | 201912346的... |
| 230测试1049的电站 | | | | | | | | 230测试1049的... |
| 50KTL的电站 | | | | | | | | 50KTL的电站 |
| 80k_s2868-A1806092... | | | | | | | | 80k_s2868-A1806092... |
| A1234567890的电站 | | | | | | | | A1234567890的... |
| A1234567899的电站 | | | | | | | | A1234567899的... |
| A12345679的电站测试... | | | | | | | | A12345679的电... |
| A14010200618的电站_... | | | | | | | | A14010200618的... |
| A14010200939的电站_... | | | | | | | | A14010200939的... |
| A1401020157的电站_b... | | | | | | | | A1401020157的... |
| A1405069879的电站 | | | | | | | | A1405069879的... |
| A1408131616的电站_w... | | | | | | | | A1408131616的... |
| A1505050208的电站 | | | | | | | | A1505050208的... |
| A1610260698的电站 | | | | | | | | A1610260698的... |
| A161215002的电站 | | | | | | | | A161215002的... |
| A161215003大机接入1... | | | | | | | | A161215003大... |
| A1702052626的电站 | | | | | | | | A1702052626的... |
| A1704220148的电站 | | | | | | | | A1704220148的... |
| A17060111118的电站 | | | | | | | | A17060111118的... |
| A170620272的电站_w... | | | | | | | | A170620272的... |
| A1707025188的电站 | | | | | | | | A1707025188的... |
| A1707206125的电站 | | | | | | | | A1707206125的... |
| A1708044457的电站 | | | | | | | | A1708044457的... |

5.1 Query Device


Select inverter model, country (region), grid type, and version No., and then click "Search" to search corresponding device.

This screenshot shows a filtered search results table for the inverter model "SHSK-20". The search filters are set to "SHSK-20" for Inverter model, "All" for Country(region), "50Hz" for Grid type, and "All" for Version no. The table has the same structure as the previous screenshot, listing various inverter units. The first few rows are as follows:


| Plant name | Device name | Device SN | Inverter model | Country(region) | Grid type | Version no. | Device space | Operation |
|-----------------|-------------|--------------|----------------|-------------------|-----------|----------------|--------------|------------------|
| A17072025188的电站 | SHSK_1 | A1707202518 | SHSK-20 | Australia | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A17072025188的... |
| A1709159998的电站 | SHSK_1 | A1709159998 | SHSK-20 | Australia | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A1709159998的... |
| A1802068828的电站 | SHSK_1 | A1802068828 | SHSK-20 | Australia | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A1802068828的... |
| A1802068838的电站 | SHSK_2 | A1802068838 | SHSK-20 | United Kingdom | 50Hz | 0-0.0.0.0-0.0- | 0.0 | A1802068838的... |
| A1802068838的电站 | SHSK_1 | A1802068838 | SHSK-20 | United Kingdom | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A1802068838的... |
| A18052443568的电站 | SHSK_1 | A1805244356 | SHSK-20 | Australia Energex | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A18052443568的... |
| A18061631488的电站 | SHSK_2 | A18061631488 | SHSK-20 | United Kingdom | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A18061631488的... |
| A18111914968的电站 | SHSK_1 | A18111914968 | SHSK-20 | Australia | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A18111914968的... |
| A18111915448的电站 | SHSK_1 | A18111915448 | SHSK-20 | Australia | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | A18111915448的... |
| HBV180206125的电站 | SHSK_2 | A180206125 | SHSK-20 | United Kingdom | 50Hz | C80-1.0.17.0-A | B0-1.0.17.0 | HBV180206125的... |


5.2 Command Line Parameter Setup

Step1 Select a plant on the left and a plant device, and click "Command line parameters setup" to enter the corresponding interface.




Step2 Click 【Add】 to fill in parameter address, data type, and set value. Select an instruction to be delivered, and click 【Send down instruction】 to enter login password.





Step3 Enter the correct login password. Then a parameter setting interface pops up.




Task name and timeout time can be set. The timeout time can be 0.5h, 1h, and 72h, and the user can select the time according to operation time and parameter setting time of the inverter. After setting, click 【Confirm】 , and the system generate the parameter delivery task. In addition, history tasks can be viewed.

Step4 Click "View" on the operation bar, to view the task. Click "Cancel the task" to cancel the latest parameter setting.


5.3 Initial Grid Connection Setting

Step1 Select a plant on the left and a plant device, and click "Initial grid connection", to enter the country and grid type interface.



Step2 After selecting the county, grid type and related country parameters, click 【Send down instruction】 , and a prompt dialog box pops up.

Step3 Enter the correct login password. Then a parameter setting interface pops up.




Task name and timeout time can be set. The timeout time can be 0.5h, 1h, and 72h, and the user can select the time according to operation time and parameter setting time of the inverter. After setting, click 【Confirm】 , and the system generate the parameter delivery task. In addition, history tasks can be viewed.

Step4 Click "View" on the operation bar, to view the task. Click "Cancel the task" to cancel the latest parameter setting.

| Task list | | | | | | |
|-----------|---|---------------------|---------------------|----------|--|--|
| NO. | Task name | Operating Time | Complete time | Operator | Task status | Operation |
| 1 | 2019-04-10 10:13 Remote parameter setting | 2019-04-10 10:14:17 | | glm | Executing | View [Cancel the task] |
| 2 | 2019-04-10 09:52:03 远程参数设置 | 2019-04-10 09:52:20 | 2019-04-10 09:52:49 | testapp | Success : 137 Piece Failed : 0 Piece Timeout : 0 Piece | View |
| 3 | 2019-04-09 17:21:03 远程参数设置 | 2019-04-09 17:21:02 | 2019-04-09 17:21:24 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece | View |
| 4 | 2019-04-09 17:17:17 远程参数设置 | 2019-04-09 17:17:12 | 2019-04-09 17:17:34 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece | View |
| 5 | 2019-04-09 17:09:03 远程参数设置 | 2019-04-09 17:09:19 | 2019-04-09 17:09:24 | testapp | Success : 1 Piece Failed : 0 Piece Timeout : 0 Piece | View |
| 6 | 2019-04-09 17:05:25 远程参数设置 | 2019-04-09 17:05:24 | 2019-04-09 17:05:25 | testapp | Success : 0 Piece Failed : 0 Piece Timeout : 20 Piece | View |
| 7 | 2019-04-09 16:38:06 远程参数设置 | 2019-04-09 16:38:06 | 2019-04-09 16:38:27 | testapp | Success : 32 Piece Failed : 0 Piece Timeout : 0 Piece | View |
| 8 | 2019-04-09 16:22:58 远程参数设置 | 2019-04-09 16:22:58 | 2019-04-09 16:52:59 | testapp | Success : 0 Piece Failed : 0 Piece Timeout : 2 Piece | View |
| 9 | 2019-04-09 15:45:41 远程参数设置 | 2019-04-09 15:45:41 | 2019-04-09 15:46:12 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece | View |

5.4 Parameter Setting

Step1 After setting the country and grid type, click "Setting" to enter the inverter parameter setting interface and set the system parameter, protection parameter, and power regulation mode.



[Send down instruction](#)

Step2 After parameter setting, click 【Send down instruction】 , then a dialog box pops up, and enter the login password into it.

Step3 When the password is verified, a parameter setting page pops up. Edit task and timeout time, and click 【Confirm】 .The history tasks can be viewed.

5.5 View History Tasks

Click "Task list" to view history tasks.

| Task list | | | | | | |
|-----------|--|---------------------|---------------------|----------|---|--|
| NO. | Task name | Operating Time | Complete time | Operator | Task status | Operation |
| 1 | 2019-04-10 10:11Remote parameter setting | 2019-04-10 10:14:17 | | ghm | Executing | View [Cancel the task] |
| 2 | 2019-04-10 09:52读取故障参数设置 | 2019-04-10 09:52:20 | 2019-04-10 09:52:49 | testapp | Success : 137 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 3 | 2019-04-10 17:12:01读取故障参数设置 | 2019-04-10 17:12:02 | 2019-04-10 17:12:04 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 4 | 2019-04-10 17:17读取故障参数设置 | 2019-04-10 17:17:12 | 2019-04-10 17:17:34 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 5 | 2019-04-09 17:09读取故障参数设置 | 2019-04-09 17:09:19 | 2019-04-09 17:09:24 | testapp | Success : 1 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 6 | 2019-04-09 17:05读取故障参数设置 | 2019-04-09 17:05:24 | 2019-04-09 17:05:25 | testapp | Success : 1 Piece Failed : 0 Piece Timeout : 20 Piece Cancel : 20 Piece | View |
| 7 | 2019-04-09 16:36读取参数设置 | 2019-04-09 16:36:06 | 2019-04-09 16:36:27 | testapp | Success : 82 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 8 | 2019-04-09 16:22读取故障参数设置 | 2019-04-09 16:22:58 | 2019-04-09 16:52:59 | testapp | Success : 0 Piece Failed : 0 Piece Timeout : 2 Piece Cancel : 0 Piece | View |
| 9 | 2019-04-09 15:45读取故障参数设置 | 2019-04-09 15:45:41 | 2019-04-09 15:46:12 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |

Total 5001 | 10/page | < 1 2 3 4 5 6 ... 501 > Go to 1

Select a time range and task name to view the corresponding history task.

Click the "View" button corresponding to the task named "Remote parameter query" to view information such as execution result and read-back value.

Task list

| NO. | Task name | Operating Time | Complete time | Operator | Task status | Operation |
|-----|---|---------------------|---------------------|----------|---|--|
| 1 | 2019-04-10 10:13 Remote parameter setting | 2019-04-10 10:14:17 | | ghm | Executing | View Cancel the task |
| 2 | 2019-04-10 09:52 远程参数查询 | 2019-04-10 09:52:20 | 2019-04-10 09:52:49 | testapp | Success : 137 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 3 | 2019-04-09 17:21 远程参数查询 | 2019-04-09 17:21:02 | 2019-04-09 17:21:04 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 4 | 2019-04-09 17:17 远程参数查询 | 2019-04-09 17:17:12 | 2019-04-09 17:17:34 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 5 | 2019-04-09 17:09 远程参数设置 | 2019-04-09 17:09:19 | 2019-04-09 17:09:24 | testapp | Success : 1 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 6 | 2019-04-09 17:05 远程参数查询 | 2019-04-09 17:05:24 | 2019-04-09 17:35:25 | testapp | Success : 0 Piece Failed : 0 Piece Timeout : 20 Piece Cancel : 20 Piece | View |
| 7 | 2019-04-09 16:36 远程参数设置 | 2019-04-09 16:36:06 | 2019-04-09 16:36:27 | testapp | Success : 32 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |
| 8 | 2019-04-09 16:22 远程参数查询 | 2019-04-09 16:22:58 | 2019-04-09 16:52:09 | testapp | Success : 0 Piece Failed : 0 Piece Timeout : 2 Piece Cancel : 0 Piece | View |
| 9 | 2019-04-09 15:45 远程参数查询 | 2019-04-09 15:45:41 | 2019-04-09 15:46:12 | testapp | Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | View |

Total 501 / 10/page < 1 2 3 4 5 6 ... 501 > Go to : 1

Task name : 2019-04-09 17:21 远程参数查询

| Plant name : | All | Inverter SN : | Search | Export | | | |
|---|-------------|--------------------------|------------------------|--|-----------|-----------------|------------------|
| Parameter setting execution result : Total set : 43 Piece Executing : 0 Piece Wait for execution : 0 Piece Success : 43 Piece Failed : 0 Piece Timeout : 0 Piece Cancel : 0 Piece | | | | | | | |
| NO. | Plant name | Device space+Device name | Inverter SN | Execute instruction | Set value | Read-back value | Execution result |
| 1 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | On / Off | -- | On | Success |
| 2 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Energy Adjustment | -- | 0 | Success |
| 3 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Country(region) | -- | China | Success |
| 4 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Protection series | -- | 2-stage | Success |
| 5 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Underfrequency primary protection value | -- | -- | Success |
| 6 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | I-Vmax | -- | -- | Success |
| 7 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Underfrequency primary protection value | -- | -- | Success |
| 8 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | I-Fmax | -- | -- | Success |
| 9 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Grid overvoltage multi-level protection recovery v | -- | 500.5 | Success |
| 10 | A1812016596 | 13924575G136TX_001_001 | Y1801090017 | Undervoltage secondary protection recovery value | -- | 488.8 | Success |

Total 43 / 10/page < 1 2 3 4 5 6 ... 501 > Go to : 1

Click "Export" to download the read-back values.

6 Firmware Update



Only installer/retailer has the upgrading permission.

Click "Firmware update" to enter the corresponding interface.

6.1 Firmware Update

On this interface, the version of the software associated with the device in the plant system can be upgraded remotely. The steps are as follows:

Step1 Click "Firmware update" to enter the firmware update interface.

Step2 Select, from the device list bar on the left, the plant whose device needs to be updated. (Batch

operation is feasible).

Step3 Select "Device type" and "Device model" and import the device serial number. Currently, the following two importing methods are available:

- Fill in the device serial number.
- Click "Device SN import" to import SNs in batch.

Step4 Select a device internal module, for example, ARM, BAT, and BOOT. Enter the version corresponding to the module.

Step5 Select a device and click "Firmware update".



Step6 Select an "Update package", and click "Upgrade".

6.2 View history update tasks

Click "🕒" to view history information.

| Check history | | | | | | | | | | |
|---------------|----------------------|----------------------|---------------|----------------------|---------------------|----------|-----------------------|--------------------|---------------|----------------------|
| 时间 | | Device type | Device model | Task start time | Task end time | Executor | Task execution status | Success statistics | Task progress | Operation |
| 2018-01-25 | 2019-01-25 | Please select | Please select | 2019-01-18 15:22:55# | 2019-01-18 15:22:46 | ghm | Operation completed | 1/1 100% | 1/1 100% | View |
| | | KTL-M(逆变器固件升级) | SG8KTL-M | | | | | | | |
| 2 | 2018-07-29 14:09:02# | Inverter | SG20KTL-M | 2018-07-28 09:20:36 | 2018-07-28 11:20:37 | ghm | Operation completed | 0/1 0% | 1/1 100% | View |
| 3 | 2018-07-29 09:47:20# | Inverter | SG20KTL-M | 2018-07-25 09:47:10 | 2018-07-25 09:57:04 | ghm | Operation completed | 1/1 100% | 1/1 100% | View |
| 4 | 2018-07-23 11:09:02# | Inverter | SG8KTL-M | 2018-07-23 11:10:50 | 2018-07-23 11:10:51 | ghm | Operation completed | 0/1 0% | 1/1 100% | View |
| 5 | 2018-07-21 07:08:46# | Communication module | E-Net V11 | 2018-05-21 07:08:03 | 2018-05-21 09:39:04 | ghm | Operation completed | 0/1 0% | 1/1 100% | View |
| 6 | 2018-05-21 07:24:46# | Communication module | E-Net V11 | 2018-05-21 07:24:41 | 2018-05-21 09:24:42 | ghm | Operation completed | 0/1 0% | 1/1 100% | View |
| 7 | 2018-05-21 07:35:46# | Communication module | E-Net V11 | 2018-05-21 07:15:51 | 2018-05-21 09:15:52 | ghm | Operation completed | 0/1 0% | 1/1 100% | View |

Select a time range, device type, device model, and goal software version to view the corresponding history tasks.

7 String IV Curve Scan and Diagnosis



Only installer/retailer has the string IV curve scan and diagnosis permission.

Step1 Click "string IV curve scan and diagnosis", to enter the corresponding interface.

The screenshot shows the iSolarCloud web interface. On the left, there is a sidebar with various menu items: Home, Fault, Report, Settings, Firmware update, String IV curve scan and diagnosis (which is highlighted with a blue box), Info, Help, Account, Me, Account settings, Account and security, Background management, and Logout. The main content area displays a tree view of plant components under 'Input plant name'. A specific node, 'A12345678900000000000000000000000', is selected and highlighted with a blue box. At the bottom of the main area, there are buttons for 'Select all', 'Time of the recent examination: 2019-04-08 10:05', and 'Start examination'.

On the top of the interface display 【Unit level scan】 , 【Inverter level scan】 , 【Check history】 , 【Setting】 .

At the lower part display all grid-connected points of the plant and unit graph list.

On the bottom display "Select All", "Time of the recent examination", and "Start examination".

Step2 Select a plant from the tree diagram on the left.

Click 【Setting】 to enter the "IV intelligent curve analysis" interface.


You will enter the "Plant parameter setting" interface by default, on which module parameters applicable to the whole plant can be set.

The screenshot shows the 'IV Intelligent curve analysis' interface. It features two tabs at the top: 'Plant parameter setting' (which is active) and 'Unit parameter setting'. The 'Plant parameter setting' tab contains several input fields: 'STC irradiance' (3000 W/m²), 'STC battery temperature' (25 °C), 'NOCT irradiance' (800 W/m²), 'Environment detecting instrument for calculating' (dropdown menu), 'Irradiation intensity' (W/m²), 'Temp-PV module' (°C), 'PV module model' (PVM M200P R3), 'The single string component number' (21), 'Component run date' (2019-02-12), and 'Minimum radiation Intensity threshold' (400 W/m²). At the bottom right of the form is a 'Save' button.


Click 【Unit parameter setting】 , select an inverter, and click 【Setting】 to set the corresponding parameters. Click 【Batch settings】 to set parameters of multiple selected inverters at the same time.

| IV Intelligent curve analysis | | | | | |
|-------------------------------|--------------|------------------------|------|----------------|--|
| Plant parameter setting | | Unit parameter setting | | Batch settings | |
| NO. | Inverter | Grid-connected point | Unit | Operation | |
| 1 | HME_30KTL-28 | grid1 | WESI | Settings | |
| 2 | HME_30KTL-27 | grid1 | WESI | Settings | |
| 3 | HME_30KTL-20 | grid1 | WESI | Settings | |
| 4 | HME_30KTL-29 | grid1 | WESI | Settings | |
| 5 | HME_30KTL-1 | grid1 | WESI | Settings | |
| 6 | HME_30KTL-2 | grid1 | WESI | Settings | |
| 7 | HME_30KTL-0 | grid1 | WESI | Settings | |
| 8 | HME_30KTL-4 | grid1 | WESI | Settings | |
| 9 | HME_30KTL-5 | grid1 | WESI | Settings | |
| 10 | HME_30KTL-6 | grid1 | WESI | Settings | |

Step3 Click 【Unit level scan】, select a device, and click 【Start examination】. Enter the login password on the pop-up window, and click 【Confirm】.



After the scanning starts, the system will determine whether the parameters are configured. If not, the parameter configuration interface will be linked to. Alternatively, users can click 【Setting】 to enter the parameter setting interface, for which, refer to **Step 2**.



After the instruction is delivered successfully, the page status will be refreshed in real time, and scanning results and progress will be displayed.

The unit is in the "Scanning..." state.

After the scanning, click 【Examination report】 to view the scanning result.

You will enter "IV intelligent curve analysis" interface by default, on which abnormal string information will be displayed. Click 【View】 to enter the "String diagnosis analysis" interface.

Close the "String diagnosis analysis" interface, and click 【IV Curve】 so as to view the IV curve of abnormal string by default.


Step4 Return to the "IV intelligent curve analysis" interface, click the button 【Inverter level scan】 , select a device, and click the button 【Start examination】 , the same as **step 3**.

Step5 Return to the "IV intelligent curve analysis" interface and click 【Check history】 , to view the history scanning results.

8 Other Operations

8.1 User Information

Click the account to enter the user information interface, on which users can bind an e-mail address, add a contact number, select a country (region), and set the time zone.




The installer/retailer can view his organization code, and the owner does not have organization code.

8.2 Account and Security

Click "Account and security" to enter the account and security interface.


Bind phone number and email address, and modify password.



8.3 Account Settings

Click "Account I settings" to enter the account settings interface.

Users can modify basic account information, perform personal setting and privacy setting.



The installer/retailer can view and modify the super-level dealer/installer organization code and can be managed by the super dealer/installer. The end user does not have superior-level organization code and related information.

8.4 Background Management

Click "Background management" to enter the corresponding interface.



Only installer/retailer can access the background management interface.

8.5 Help

Click "Help" to view the user manual corresponding to the software.

9 Appendix

9.1 System Requirements

| | |
|-------------------|--|
| Browser | Chrome recommended |
| Resolution | 1920*1080 recommended and 1366*768 supported |

9.2 Manual Description

The information contained in this document is the property of Sungrow Power Supply Co., Ltd. (referred to as "Sungrow" hereinafter). Publishing its content, either partially or in full, requires the written permission of Sungrow. Any internal company copying of the document for the purposes of evaluating the product or its correct implementation is allowed and does not require permission.

All rights reserved including the pictures, symbols, and identifiers used in this manual. Any reproduction or disclosure, even partially, of the contents of this manual is strictly prohibited without prior written authorization of Sungrow.

The content of the manual will be periodically updated or revised as per the product development. It is probably that there are changes in manuals for the subsequent module edition. Refer to the actual screen interface, and obtain the latest version at www.sungrowpower.com or from the sales department.

9.3 Contact Sungrow

Should you have any question about this product, please contact us.

China (HQ)

Sungrow Power Supply Co., Ltd
Hefei
+86 551 65327834
service@sungrowpower.com

Australia

Sungrow Australia Group Pty. Ltd.
Sydney
+61 2 9922 1522
service@sungrowpower.com.au

Brazil

Sungrow Do Brasil
Sao Paulo
+55 11 2366 1957
latam.service@sa.sungrowpower.com

France

Sungrow France – Siege Social
Paris
service.france@sungrow.co

Germany

Sungrow Deutschland GmbH
München
+49 89 324 914 761
service.germany@sungrow.co

Greece

Service Partner – Survey Digital
+30 2106044212
service.greece@sungrow.co

India

Sungrow (India) Private Limited
Gurgaon
+91 080 41201350
service@in.sungrowpower.com

Italy

Sungrow Italy
Milano
service.italy@sungrow.co

Japan

Sungrow Japan K.K.
Tokyo
+ 81 3 6262 9917
japanservice@jp.sungrowpower.com

Korea

Sungrow Power Korea Limited
Seoul
+82 70 7719 1889
service@kr.sungrowpower.com

Malaysia

Sungrow SEA
Selangor Darul Ehsan
+60 19 897 3360
service@my.sungrowpower.com

Philippines

Sungrow Power Supply Co., Ltd
Mandaluyong City
+63 9173022769
service@ph.sungrowpower.com

Thailand

Sungrow Thailand Co., Ltd.
Bangkok
+66 891246053
service@th.sungrowpower.com

Spain

Sungrow Ibérica S.L.U.
Navarra
service.spain@sungrow.co

Romania

Service Partner - Elerex
+40 241762250
service罗马尼@sungrow.co

Turkey

Sungrow Deutschland GmbH Turkey Istanbul
Representative Bureau
Istanbul
+90 212 731 8883
service.turkey@sungrow.co

UK

Sungrow Power UK Ltd.
Milton Keynes
+44 (0) 0908 414127
service.uk@sungrow.co

U.S.A, Mexico

Sungrow USA Corporation
Phoenix Arizona
+1 833 747 6937
techsupport@sungrow-na.com

Vietnam

Sungrow Vietnam
Hanoi
+84 918 402 140
service@vn.sungrowpower.com
