

# Replacement Device Procedure

## Disclaimer


The material in this document has been prepared by Sungrow Australia Group Pty. Ltd. ABN 76 168 258 679 and is intended as a guideline to assist solar installers for troubleshooting. It is not a statement or advice on any of the Electrical or Solar Industry standards or guidelines. Please observe all OH&S regulations when working on Sungrow equipment.

When replacing a Sungrow inverter or battery, the new device will self-assign, so there is no need to do anything.


The device replacement procedure applied to dongles.

## Procedure:

Log into the plant, select 'Device' from the tab, and tap the three dots



Add new device and scan the QR code, and **save**.



If the issue still persists, please take photos testing on site and contact Sungrow Service Department on 1800 786 476 or email to [service@sungrowpower.com.au](mailto:service@sungrowpower.com.au).