

Error 084 CT reverse power error

The reverse sensor connection will cause the communication error 084, which indicates that a reverse grid power error which can be caused by not setting the existing system if there is another inverter, or if the CT clamping is not pointing away from the grid to the inverter and to loads that are on the same phase as the inverter.

To clear the fault 084, please turn off the DC sources and then restart the system after reconnecting the sensor in correct direction.

Click [here](#) for instructions for setting the existing system or another inverter on the SH5K+ LCD.

Click [here](#) to watch tips for installing the energy meter with the SH5K+ energy meter installation tips.

Click [here](#) for information about installing the S100 meter with the SH5K+.

If the fault persists, please take photos testing on site and contact Sungrow Service Department.